


# PF705 firmware upgrade process

To upgrade the firmware:

- If you update firmware, all settings of PF705 will be initialized. We recommend to backup the data before updating F/W.
- Do NOT disconnect the power adapter during Firmware update.

1. Copy the file (**FWPF705.bin**) to the root dictionary of USB flash drive or SD/SDHC/MMC/MS memory card.
2. Insert the USB flash drive or SD/SDHC/MMC/MS memory card into the slot of PF705.
3. Select Firmware upgrade from the Settings menu and press OK to start the firmware upgrade process. PF705 will automatically find the new firmware file.



4. If PF705 detect the firmware, a “Yes / No” selection message will be shown. Use LEFT or RIGHT to select “Yes” and press OK to perform the system upgrade. If you do not want to upgrade, press “No” to return to the Settings menu.
5. After updating firmware success, please unplug the AC power cord.